


Connection to a ECU with  
**LOW SIDE DRIVER Output:**  
(modified Manual ECU)



Connection to a ECU with  
**HIGH SIDE DRIVER Output:**  
(Automatic ECU)

