



You need to add the following Parts to the manual ECUs* to make the additional PWM Output (Low Side Driver) on Pin B24 work:

TIP122 (NPN Power Transistor) 1kOhm Resistor 1N4001 Diode





^{* (}on automatic ECUs there is allready a High Side Driver installed)