



Connection of a Pierburg CWA200

- 1 - +12 Volt
- 2 - PMW Signal from ECU
- 3 - [not connected]
- 4 - Ground

**Connection to a ECU with
LOW SIDE DRIVER Output:
(modified Manual ECU)**



**Connection to a ECU with
HIGH SIDE DRIVER Output:
(Automatic ECU)**



**Recommended Frequency
100 Hz**